


Power On/Off

Strom AN/AUS | Mise sous/hors tension | Spegnimento e accensione |
Encender/Apagar | Stroom aan/uit | Включение/выключение питания |
電源のオン/オフ | 전원 켜기/끄기 | 开机/关机 | 開啟/關閉電源



Use Output Ports


Output Ports verwenden | Utilisez les ports de sortie | Utilizzare
le porte di uscita | Usar puertos de salida | Uitgangen gebruiken |
Используйте выходные порты | 出力ポートを使用 | 출력 포트 사용 |
使用输出端口 | 使用輸出埠



USB-A / USB-C



AC



Extra Battery



DC5521






12V DC




Charge Your Power Station



Ihre Powerstation laden | Chargez votre station électrique |
Ricaricare la power station | Cargue su estación de energía |
Uw energiestation opladen | Поставьте электростанцию на
зарядку | ポータブル電源の充電 | 전원 스테이션 충전 | 为便携电源
充电 | 為您的戶外電源充電




Extra Battery



Solar Charging



Car Charging




AC Charging



Read
LCD Screen

LCD-Bildschirm lesen | Lisez les informations affichées sur l'écran LCD | Leggere lo schermo LCD | Leer pantalla LCD | Het lcd-scherm lezen | Отображение данных на экране ЖК-дисплея | 液晶画面を読み取る | LCD 화면 읽기 | 查看显示屏 | 閱讀 LCD 屏幕



1 Battery Level & Remaining Charging/Discharging Time

Ladezustand der Batterie und verbleibende Lade-/Entladezeit
Niveau de charge et temps de charge/décharge restant
Livello della batteria e tempo di carica/scarica residuo
Nivel de la batería y tiempo de carga/descarga restante
Accuniveau en resterende op-/ontlaadtijd
Уровень заряда и оставшееся время зарядки/разрядки
バッテリーレベルと残りの充電 / 放電時間
배터리 잔량 및 남은 충전 / 방전 시간
电量和剩余充 / 放电时间
電池電量和剩餘充 / 放電時間

2 Power Input & Output Details

Details zu Stromeingang und -ausgang
Détails de l'entrée et de la sortie d'alimentation
Dettagli sull'ingresso/uscita di alimentazione
Detalles de entrada y salida de energía
Details over het in- en uitgangsvermogen
Данные о входном и выходном энергопотоке
電力入力と出力の詳細
전원 입력 및 출력 상세 정보
輸入 / 輸出功率详情
電源輸入和輸出詳細資料

3 Error Icon

Fehlersymbol|cône d'erreur | Icona di errore | Icono de error | Foutpictogram |
Значок ошибки | エラーアイコン | 오류 아이콘 | 故障图标 | 錯誤圖示




Troubleshooting

Fehlerbehebung | Dépannage | Risoluzione dei problemi |
Solución de problemas | Problemen oplossen | Поиск и
устранение неисправностей |トラブルシューティング |
문제 해결 | 故障排查 | 疑難排解


Control Via
EcoFlow App

Steuerung über die EcoFlow App | Contrôlez votre station
électrique via l'application EcoFlow | Controllo tramite app
EcoFlow | Control a través de la aplicación EcoFlow | Bediening
via de EcoFlow-app | Контролируйте работу устройства с
помощью приложения EcoFlow | EcoFlow アプリで制御で
きます | EcoFlow 앱을 통한 제어 | 使用EcoFlow App控制 | 透過
EcoFlow App 控制





What's
in the Box

Im Lieferumfang enthalten | Contenu de la boîte |
Cosa contiene la confezione | Contenido | Wat zit er in de doos |
Что в комплекте | 同梱物 | 구성품 | 包装清单 | 包裝內容




EcoFlow DELTA 3 1500



AC



Manuals



Raccolta carta

ECO FLOW

1403011194

QUICK START GUIDE

V1.1



EcoFlow DELTA 3 1500

For more details, check the latest user manual or
related documents.

🔍 <https://www.ecoflow.com/support/>

© 2025 EcoFlow Inc. All rights reserved.



App



User Manual